



ENCLOSED WITH THE QUICK DRAW WATER BOTTLE HOLDER ARE THE FOLLOWING ITEMS

- A: QUICK DRAW FRAME**
- B: TWO (2) "J" SHAPED STAINLESS STEEL SUPPORT BRACKETS**
- C: TWO (2) 3/4 INCH SOCKET BUTTON BOLTS WITH WASHERS AND NUTS. REQUIRES #3 HEX HEAD WRENCH (ALLEN KEY).**
- D: TWO (2) HALF INCH SOCKET BOLTS WITH WASHERS AND NUTS. REQUIRES #4 HEX HEAD WRENCH (ALLEN KEY).**
- E: TWO (2) 90 DEGREE ELBOWS (L SHAPED) THREADED ON BOTH ENDS WITH WASHERS AND NUTS.**
- F: FOUR (4) RUBBER END CAPS FOR PLACEMENT OVER EXPOSED ENDS OF 90 DEGREE ELBOWS.**
- G: FOUR (4) HALF INCH SOCKET BUTTON BOLTS WITH WASHERS AND NUTS. REQUIRES #4 HEX HEAD WRENCH (ALLEN KEY).**

INSTALLATION OF THE QUICK DRAW BOTTLE HOLDER

THANK YOU FOR PURCHASING THE ISM QUICK DRAW REAR SADDLE MOUNT BOTTLE HOLDER. FOLLOWING WILL BE STEP BY STEP INSTRUCTIONS FOR PROPER MOUNTING OF THE QUICK DRAW BOTTLE HOLDER TO YOUR SADDLE.

PRIOR TO BEGINNING WE RECOMMEND YOU MARK THE HEIGHT OF YOUR SEAT POST WITH TAPE AND REMOVE THE SADDLE AND POST FROM YOUR BICYCLE.

YOU WILL NEED THE FOLLOWING TOOLS TO COMPLETE INSTALLATION;

1. #3 AND #4 HEX HEAD WRENCHES (ALLEN KEYS)
2. CRESCENT WRENCH AND A 1/4 INCH OPEN ENDED WRENCH
3. NEEDLE NOSE PLIERS

COMPLETE THE STEPS BELOW ON BOTH THE RIGHT AND LEFT SIDES OF THE QUICK DRAW TO PROPERLY SECURE THE DEVICE TO YOUR SADDLE.

1: PLACE THE FRONT OF THE QUICK DRAW AGAINST THE RAILS AT THE REAR OF THE SADDLE.

STEPS 2 AND 3 ARE INTERCHANGABLE AND CAN BE REVERSED BY THE INSTALLER

2: ATTACH THE "J" SHAPED SUPPORT BRACKETS (B) TO THE REAR OF THE SADDLE RAILS AND SECURE THE FLAT END WITH THE HALF INCH SOCKET BOLTS (D) TO ONE OF THE THREE HOLES AVAILABLE IN THE FRAME OF THE QUICK DRAW. DO NOT TIGHTEN THE BOLTS AT THIS TIME.

3: PLACE THE 90 DEGREE (L SHAPED) ELBOWS (E) AROUND THE RAILS AND THROUGH THE OPENINGS PROVIDED IN THE BRACKET AND SECURE WITH THE NUTS. THIS IS A SNUG FIT. SOME INSTALLERS PREFER TO SLIGHTLY BEND THE 90 DEGREE ELBOW, INWARD, TO FACILITATE THE FIT.

4: SECURE THE TOP PORTION OF THE "J" SHAPED SUPPORT BRACKET (B) WITH THE 3/4 INCH SOCKET BUTTON BOLT. THE 3/4 INCH SOCKET BUTTON BOLT WILL SECURE THE SUPPORT BRACKET TO THE RAIL.

5: WHEN ALL BOLTS AND ELBOWS ARE ATTACHED MAKE SURE THE QUICK DRAW IS FLAT AGAINST THE SADDLE AND TIGHTEN ALL THE NUTS AND BOLTS. THE "J" SHAPED SUPPORT BRACKETS (B) WILL NATURALLY BEND AS THE BOLTS ARE TIGHTENED.

6: PLACE THE RUBBER END CAPS (F) OVER THE EXPOSED THREADED ENDS OF THE 90 DEGREE ELBOWS (E) AFTER THE NUTS ARE TIGHT AND SECURE.

7: USE THE HALF INCH SOCKET BUTTON BOLTS TO SECURE WATER BOTTLE CAGES (NOT INCLUDED) TO THE QUICK DRAW WATER BOTTLE HOLDER.

MONTHLY CHECKING OF BOLTS AND NUTS IS RECOMMENDED

